

No-Till Planter Tips for Travel & Planting

- Travel at no more than 20 mph and travel with 4 way flashers on
- Disengage pin from right wheel to travel
- Engage pin in right wheel to engage wheel for planting
- Need 4-way plug for towing lights
- Plug hydraulics in to lift cylinders; remove block on each side and store in storage box
- Do not make sharp turns while engaged in ground position
- 3 Seed boxes (inside the box is a list of appropriate seeds:
 - Front seed box is for small seed (clover, alfalfa, etc)
 - Middle box is for hard-to-plant seeds (native seeds)
 - Back box is for large seed (soybeans, oats, barley, brome)
- Clean the machine boxes out when done
- **Grease all knobs, disks, and drives after use**
- **Record acreage meter to document acres planted for payment purpose**